

AV Series Dynamic Mount


Tilt

 Intuitive grab and move operation enhances the user experience

No knobs or tools required to reposition the display Precise control of operating effort ensures ideal "feel" Holds securely, even in applications with dynamic loading

- Consistent repeatable operation
- Fully enclosed for optimum cleanability

Product Detail




Installation


- 1. Determine desired mounting location
- 2. Attach using M5 X 0.8 screws as shown


Caution: Because of the wide variety of available wall materials, it is the installer's responsibility to ensure that the materials, and structure to which the tilt mount is fastened will provide adequate support.

3. Attach display using manufacturer's recommended hardware

Installation









VESA MIS-D, 100, C





AV Series Dynamic Mount


Tilt




Specification and Selection

Step 1


Determine display weight and distance (d) from mounting surface to center of gravity.



Step 2Use chart below to select model (101, 102 or 103).



Step 3Complete part number by selecting model and color options below.



For complete installation and operation instructions please consult the product manual included in every package or available to download from www.southco.com

Dimensions in millimeters (inch) unless otherwise stated

southco®

Smooth operation enhances the user experience

- Adjust the display without knobs or tools
- Holds securely

Material and Finish

Aluminum alloy, powder coated

Performance Details

Cycle performance: 20,000 cycles within \pm 20% of static torque specification

Max. dynamic working load: Model 101 and 103: 70N (15.7lbf) Model 102: 100N (22.5lbf) Average ultimate load: 1845N (414.8lbf)

Part Number

See table

Part Number Example AV-D30-5T101-50 = Dynamic tilt mount, Model 101, black

